MDR-RF845RK

SERVICE MANUAL

AEP Model
UK Model

Ver 1.0 2000. 07

MDR-RF845RK is composed of the following models.
As for the service manual it is issued for each component model, then please refer to it.

COMPONENT MODEL NAME FOR MDR-RF845RK

Headphones	MDR-RF845R
Transmitter	TMR-RF845R

PARTS LIST

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

Ref. No.	Part No.	Description	Remarks
		ACCESSORIES & PACKING MATERIALS	
		**********	
⚠	1-465-948-11	ADAPTOR, AC (AC-S901K)(AEP)	
⚠	1-473-590-11	ADAPTOR, AC (AC-S901) (UK)	
⚠	1-473-606-11	ADAPTOR, PLUG	
⚠	1-476-179-11	ADAPTOR, AC (AC-S9010) (AEP)	
	1-559-906-32	CORD, CONNECTION	
	3-222-708-11	MANUAL,INSTRUCTION (ENGLISH)(AEP,UK)	
	3-222-708-21	MANUAL,INSTRUCTION (FRENNCH,GERMAN,SPANISH,DUTCH,ITALIAN, PORUTGUESE) (AEP)	

SPECIFICATIONS

General

Carrier frequency	863.5 – 864.5 MHz
Channel	Ch1, Ch2, Ch3
Modulation	FM stereo
Frequency response	20 – 20,000 Hz

Transmitter TMR-RF845R

Power source	DC 9 V: supplied AC power adaptor
Audio input	phono jacks/stereo mini jack
Dimensions	Approx. 150 mm dia × 108 mm ($6 \times 4\ ^1/_3$ in.) (w/h)
Mass	Approx. 190 g (6.2 oz.)

Headphones MDR-RF845R

Power source	DC 2.4 V: Built-in rechargeable battery
Mass	Approx. 240 g (8.1 oz.) incl. built-in rechargeable battery

Built-in Ni-Cd rechargeable battery

Model name	NC-AA
Voltage	1.2 V
Capacity	700 mAh

Design and specifications are subject to change without notice.

WIRELESS STEREO HEADPHONE SYSYTEM

SONY®

Setting up the transmitter

1 Connect the transmitter to audio / video equipment. Select one of the hookups below depending on the jack type:

Ⓐ To connect to a headphones jack



5-Ⓐ Turn up the volume to a moderate level with the VOL control.
Press the TUNING button briefly for automatic tuning of the headphones. If you do not receive a clear audio signal, press it again.

Ⓐ MDR-RF845R



Auto power on/off function

When you remove the headphones from your head, the power turns off automatically. Do not allow the self adjusting band to be pulled up, otherwise the headphones will be switched on.



The power turns on.